

Table of Contents

IMPORTANT NOTICE	1
SAFETY INSTRUCTIONS	1
MAINTENANCE AND CARE	2
INTENDED USE	2
CHILDREN	3
CHARGER AND RECHARGEABLE BATTERIES	3
CONFORMITY	5
DISPOSAL OF OLD DEVICES	5
NOTE ON THIS MANUAL	5
INTRODUCTION	6
PACKAGE CONTENTS	6
CONTROLS AND BUTTONS	7
GETTING STARTED	8
CHARGING THE BATTERY	8
INSERTING THE BATTERY	9
INSERTING THE SD CARD	10
SWITCHING THE CAMERA ON AND OFF	11
POWER-SAVING FUNCTION	11
TOGGLING BETWEEN RECORDING AND PLAYBACK MODE	11
LCD DISPLAY	11
PLAYBACK MODE	12
RECORDING MODE	13
CHANGING THE DISPLAYED INFORMATION	14
SETTING THE MENU LANGUAGE	15
SETTING DATE AND TIME	15
CAPTURING PICTURES	16
QUICK GUIDE	16
USING THE ZOOM FUNCTION	17
USING THE FLASH	18

RECORD MENU	19
RESOLUTION	20
QUALITY	20
METERING	21
WHITE BALANCE	21
ISO	22
EXPOSURE	23
DRIVE MODE	23
AEB (AUTOMATIC EXPOSURE BRACKETING)	24
HIGHLIGHT	24
SHARPNESS	25
EFFECT	25
DATE STAMP	26
DIGITAL ZOOM	26
AF LAMP	26
SETUP	27
RECORD PROGRAMMES	27
Q MODE	29
MACRO MODE	29
<u>RECORDING VIDEO CLIPS</u>	<u>30</u>
QUICK GUIDE	30
VIDEO MENU	31
MOVIE SIZE	32
METERING	32
WHITE BALANCE	32
SETTING	32
<u>PLAYING BACK IMAGES AND VIDEO CLIPS</u>	<u>33</u>
QUICK GUIDE	33
PLAYBACK MENU	34
LOCK	35
DELETE	35
SLIDE SHOW	36

DPOF	37
COPY TO CARD	38
EFFECT	38
ROTATE	38
RESIZE	39
VOICE MEMO	39
START-UP IMAGE	40
SETTING	40
USING THE THUMBNAIL VIEW	41
ENLARGING PICTURES	42
<u>AUDIO RECORDING AND PLAYBACK</u>	43
AUDIO RECORDING	43
AUDIO PLAYBACK	44
<u>ADVANCED SETTINGS</u>	45
SETUP MENU	45
SOUNDS	46
AUTO REVIEW	46
ENERGY-SAVING FUNCTION	47
FILE NUMBER	47
TV OUT	47
USB	48
START-UP IMAGE	48
FORMAT	48
RESET ALL	49
<u>CONNECTORS</u>	50
VIEWING PICTURES ON A TELEVISION SCREEN	50
COPYING PICTURES TO A COMPUTER	51
USING THE USB CABLE	51
USING A CARD READER	53

INSTALLING THE SOFTWARE	55
SYSTEM REQUIREMENTS	55
SUPPLIED SOFTWARE	55
APPENDIX	57
POWER INDICATOR STATUS	57
TIPS FOR TAKING BETTER PICTURES	58
SUBJECT	58
BACKGROUND	58
CAMERA ANGLE	58
GOLDEN SECTION	58
LIGHTING	58
TROUBLESHOOTING	59
TECHNICAL SPECIFICATIONS	61
DETAILS OF GUARANTEE	63

Important Notice

Safety Instructions

- Before you use this device for the first time, please read the following notes in this manual and heed all warnings, even if you are familiar with handling electronic devices. Always check the camera works correctly.
- Keep this manual with the instructions in a safe place for future reference.
- If you sell or pass this device on to another person, it is imperative that you also hand over this manual.
- Do not try to open the camera housing or reassemble the camera. Inside there are components and high voltage. You are at risk of receiving an electric shock. Maintenance and repairs should only be carried out by qualified technicians.
- Do not look at the sun or other sources of intense light. Doing so may damage your eyesight.
- Never activate the flash near the eyes of persons or animals. This is especially dangerous for children. The flash is dangerous to your eyesight. When using the flash, stand at least one meter (3 feet) away from your subject.
- Keep the Nytech DS-7210 away from water and other liquids. Do not operate the camera with wet hands. Do not use the camera in rain or snow. Dampness can cause danger through fire or electric shock.
- Keep the Nytech DS-7210 out of the reach of children and animals to avoid accidents or damage to the camera.
- Switch the Nytech DS-7210 off immediately if you notice it emitting smoke or strange noises. Contact the Nytech customer service. Never try to repair the camera yourself.
- Only use the supplied Ktec KSAF B 060 0050 W1 UK power adapter and the supplied charger tray to recharge the Nytech DS-7210 rechargeable batteries.
- Only use this device with the supplied rechargeable battery (BYD DM6331) in order to avoid overheating, deformation of the cover, fire, electric shocks, explosion and other dangers.

- Unplug the power adapter from the mains supply before you remove the rechargeable batteries from the charger or separate the charger from the power adapter.
- In case of defect of the Nytech DS-7210 or its accessories, unplug the power adapter from the mains immediately.
- Also, when there is the possibility of thunderstorms, pull the power adapter from the wall outlet.
- Never try to heat, disassemble or short-circuit the rechargeable batteries. Do not throw the rechargeable batteries in fire.

Warning: Notice concerning separation from the mains

In order to completely disconnect the device from the mains, pull the power adapter out from the wall outlet. The wall outlet where the device is connected must be easy to access so that the power adapter can be pulled out quickly in case of emergency. Pull the power adapter out from the mains when you will not be using the device for a long while (e.g. when going on holiday) in order to avoid the danger of fire. Do not hold the power adapter with wet hands.

Maintenance and care

Servicing is required when this device has been damaged in any way, for example, when the power adapter or the housing of the Nytech DS-7210 is damaged, when liquid or objects have entered the device, when the product has been exposed to rain or moisture, when the product does not work normally or if the product has been dropped. If you notice any smoke, unusual noise or strange smells, switch off the device immediately and pull the power adapter from the power supply. In this case the device should not be used further and should be inspected by authorized service personnel. Contact qualified personnel when servicing is needed.

Intended Use

Always hold all cables by the plug and never pull on the cable itself. Never hold the power cord with wet hands as this may cause a short circuit or electric shock. Never place the device, heavy objects or furniture on the cable and take care that the cord does not become trapped, especially at the plug and sockets. Never make knots in the cable and do not tie it

together with other cords. All cables should be positioned so that nobody can trip over them or be obstructed by them. A damaged power cord can cause a fire or electric shock. Inspect the power cord from time to time. Never use adapter plugs or extension cables that do not comply with the current safety regulations in your country, and do not modify any of the power cords or electrical installations yourself. The device is not for use in rooms with a high temperature or humidity and must be kept free of dust. Position the Nytech DS-7210 on a stable, flat surface and do not place any objects on the device.

Always make sure that:

- no direct heat sources (e.g. heating) can affect the device;
- no direct sunlight or bright artificial light reaches the device;
- contact with spray and dripping water and abrasive liquids must be avoided and the device should never be operated near water, and it must especially never be immersed (do not place any objects filled with liquids such as vases or drinks near the device);
- do not place any fire sources (e.g. burning candles) on or near the device;
- do not introduce any foreign bodies into the device;
- the device must not be subject to any great temperature changes as this may cause moisture through condensation;
- the device should not be subject to excessive knocks and vibrations.

Children

Electrical appliances do not belong in the hands of children. Do not allow children to play with electrical devices when not under supervision. Children may not be able to comprehend the presence of potential risks. Rechargeable batteries and small parts represent potential choking hazards. Keep batteries out of reach of children. If a rechargeable battery is swallowed, seek medical help immediately. Keep all packaging away from children as this can cause suffocation.

Charger and Rechargeable Batteries

Insert the rechargeable batteries with the correct polarity. Never throw a rechargeable battery into fire. Remove the rechargeable battery from the Nytech DS-7210 when the device is not to be used for a long time. Non-

intended use may cause explosion and danger to life. Only replace the rechargeable battery with an equivalent or a type recommended by the manufacturer.

Respect the environment. Old rechargeable batteries do not belong in with the domestic waste. They must be handed in to a collection point for old batteries.

Conformity



The Nytech DS-7210 and the supplied accessories have been tested and approved for compliance with the basic and other relevant requirements of the EMC Directive 89/336/EEC, as well as the Low-voltage Directive 73/23/EEC.

Disposal of Old Devices



Devices marked with this symbol are subject to the European Directive 2002/96/EC. All electric and electronic devices must be disposed of separately from household waste at established bodies. Avoid hazards to the environment and dangers to your personal health by disposing of the device properly. For further information about proper disposal, contact your local government, disposal bodies or the shop where you bought the device.

Note on this Manual



This symbol denotes further information on the topic.



This symbol denotes important notes.

On page 7 of this manual you can find the meanings of the controls and buttons illustrated on the inside of the cover.

Introduction

Firstly, many thanks for having chosen this high-end Nytech DS-7210 digital camera. Please check that delivery contents are complete using the list below.

Package contents

- Nytech DS-7210 camera
- BYD DM6331 rechargeable batteries (2)
- SD memory card, 512 MB
- Charging tray Nytech AB-4330
- Ktec KSAF B 060 0050 W1 UK power adapter
- USB cable
- AV cable
- Pouch
- Carrying strap
- CD-ROM (not shown)
- User's manual (not shown)



Controls and buttons

This User manual has a fold-out cover. On the inside of the cover the camera is shown with the meanings of the controls and buttons.

Figure of back

- 1 On/Off button (Power)
- 2 Power indicator
- 3 Shutter
- 4 Zoom button
- 5 Playback button (Play)
- 6 Menu button
- 7 Eyelet for carrying strap
- 8 SET button
- 9 Four-way button
for Menu navigation (see right)
- 10 Camera mode button
- 11 Delete
- 12 Display

Figure: Four-way button



Figure of front

- 13 Self-timer lamp and auto focus lamp
- 14 Flash
- 15 Lens
- 16 Microphone

Bottom

- 17 Speaker
- 18 Tripod mount
- 19 Battery cover and
memory card
compartment



Getting Started

The camera functions with a rechargeable Lithium-Ion (BYD DM6331) battery. On delivery, the battery is not charged. Please charge the battery before first use of the camera.

Charging the Battery

Insert the rechargeable battery in the charging tray Nytech AB-4330 so that the contacts [+] and [-] correspond to the rechargeable battery and charging tray markings. Next connect the power adapter to the charging tray and plug the power adapter to a wall outlet.

The status indicator of the charging tray will light red whilst the battery is charging. When the charging process is completed, the status indicator will light green. You can then insert the rechargeable battery into the Nytech DS-7210. Depending on the charge level, the charging cycle can take up to 4 hours.



To operate the camera, only use the BYD DM6331 rechargeable Lithium-Ion battery.

Remove the rechargeable battery from the camera when the device is not to be used for a long time.

During charging, the rechargeable battery and charging device will become warm. This is not a malfunction.

If, after inserting the rechargeable battery, the indicator remains green, this means the rechargeable battery is already charged or it is not correctly inserted. In this case, check the polarities.

Inserting the Battery

When the battery is fully charged, insert it into the Nytech DS-7210 as below.

- Open the Nytech DS-7210 battery compartment by pushing the cover gently outwards. The cover will spring up by a spring mechanism.
- Insert the rechargeable battery with the mark towards the front of the camera into the battery compartment (see figure below) and push it into the housing. The rechargeable battery should be inserted gently and without offering resistance.
- Close the battery compartment cover by pressing down the flap on the housing of the camera and then by pushing it inwards till it locks. The cover clicks into place.



To remove the rechargeable battery push the unlock button outwards. The rechargeable battery will protrude a little so that you can get a hold of it and remove it.



Make sure that the camera is switched off before you remove the rechargeable battery.

Inserting the SD Card

By using the SD memory card (included in the package) you can increase the Nytech DS-7210 storage capacity for saving your photos, videos and voice recordings.

When the memory card is inserted, all the photos and videos you take will be saved onto it. If there is no memory card inserted, your photos and videos will be saved to the internal memory of the camera.



Power on the camera using the switch [1] before you insert or remove a memory card.

- Open the Nytech DS-7210 battery compartment by pushing the cover gently outwards. The cover will spring up by a spring mechanism.
- Insert the memory card with the contacts towards the front side of the camera into the card compartment and push it into the housing. The memory card clicks into place.
- Close the battery compartment cover by pressing down the flap on the housing of the camera and then by pushing it inwards till it locks. The cover clicks into place.



To remove the memory card, gently press on the inserted card. This will protrude a little so that you can get a hold of it and remove it.

Switching the Camera On and Off

Press the Power button [1] and keep it pressed down for approximately 1 second to turn it on in Recording mode. Or you can press the Play button [5] and keep it pressed down for approximately 1 second to turn the camera on in Playback mode.

Press the Power [1] button to switch off the camera.

Power-Saving Function

The Nytech DS-7210 is equipped with an automatic power-saving function to extend the rechargeable battery life. By default, the LCD display [12] powers off after one minute if the camera is not being used. Press any button to power on once again the LCD display.

You can alter the preset timeout for the energy-saving function. To do this, read page 47 – Energy-Saving Function.

The Nytech DS-7210 powers itself off if the LCD screen has been switched off for longer than one minute. Press the Power button [1] to switch the camera on again.

The energy-saving function is not enabled when:

- the camera is connected via a USB cable to a computer or printer
- a slideshow is being played back
- a video or audio file is being recorded
- a video or audio file is being played

Toggling Between Recording and Playback Mode

The Nytech DS-7210 is ready to record videos or audio files in Recording mode. In Playback mode the recorded files can be seen on the display [12].


- Press the Play button [5] to toggle between Recording and Playback mode.

LCD Display

The LCD display [12] of your Nytech DS-7210 is used to configure the shooting parameters, to check and adjust the camera settings and to display your captured images. In Recording mode, on-screen icons inform

you of the current camera settings, while in Playback mode information on the recorded image is displayed.


Playback Mode



- | | | | |
|---|---|----|----------------|
| 1 | Mode icon | 7 | Battery status |
| 2 | Lock | 8 | Date and time |
| 3 | Voice memo | 9 | Voice note |
| 4 | Current file number/total number of files | 10 | DPOF |
| 5 | Storage media | 11 | Resolution |
| 6 | Recording information | | |

A more detailed description about the Playback mode can be found on page 33.

Recording Mode




- | | | | |
|----|-----------------------|----|--------------------------|
| 1 | Recording mode | 12 | Shaky image warning icon |
| 2 | Flash indicator | 13 | Shutter speed |
| 3 | Zoom bar | 14 | Aperture value |
| 4 | Remaining pictures | 15 | Exposure |
| 5 | Storage media | 16 | Measure area |
| 6 | Macro programme | 17 | ISO |
| 7 | Self timer | 18 | White balance |
| 8 | Exposure compensation | 19 | Sharpness |
| 9 | Date stamp | 20 | Quality |
| 10 | Battery status | 21 | Resolution |
| 11 | Focus area | | |

Changing the Displayed Information


Press the SET button [8] to change the display mode of the LCD [12] as follows:

In Recording mode:





- (A) Icon display on
- (B) Grid on
- (C) All information off

In Playback mode:





- (A) Full icon display
- (B) Reduced icon display
- (C) All information off

Setting the Menu Language

1. Power the Nytech DS-7210 on by pressing and holding the Power button [1] for approx. 1 second.
2. Press the Menu button [6] to display the Settings menu.
3. Press ◀ or ▶ on the four-way button to select **Setup** (icon ) and then press the Set button [8] to open the Setup menu.
4. Press ▲ or ▼ on the four-way button to select **Language** (icon ) and then press the Set button [8].
5. Press ▲ or ▼ on the four-way button to move the highlighted bar through the different languages and select the desired language by pressing the Set button [8].
6. Press the Menu button [6] to exit the Setup menu.

Setting Date and Time

1. Power the Nytech DS-7210 on by pressing and holding the Power button [1] for approx. 1 second.
2. Press the Menu button [6] to display the Settings menu.
3. Press ◀ or ▶ on the four-way button to select **Setup** (icon ) and then press the Set button [8] to open the Setup menu.
4. Press ▲ or ▼ on the four-way button to select **Date & Time** (icon ) and then press the Set button [8].
5. Press ◀ or ▶ on the four-way button to move the highlighted bar through the different options and change the entries by pressing the four-way button (▲ or ▼).
6. Press the Set button [8] to save the selected settings.

Press the Menu button [6] to exit the Setup menu.


Capturing Pictures

Quick Guide

1. Power the Nytech DS-7210 on in Recording mode by pressing and holding the Power button [1].
2. Point the camera at the subject and check the composition of your picture on the display [12].
3. If necessary, press the Zoom button [4] to zoom in (T - Tele) or zoom out (W - Wide) on the subject.
4. Press the shutter button [3] halfway down. This will enable the auto-focus.




The Nytech DS-7210 will try to focus the area contained within the focus area. This will depend on the lighting conditions and the distance to the subject. If the camera has focused the picture successfully, the focus frame will become green, a beep will be heard and the power indicator [2] will light red.



Focus area

5. Now press the shutter button fully down to take the picture.



If the exposure time is too long (subject very dark) the shaky image warning icon  will appear on the display. In this case it is recommended that you use a tripod to stabilise the camera.

Read the chapters from page 27 to learn how to use preset programmes.

Using the Zoom Function

Your Nytech DS-7210 features a combination of optical and digital zoom allowing you to zoom in on distant subjects or to zoom out for wide-angle shots.

The optical zoom adjusts the camera lens mechanically. The digital zoom enlarges or reduces the picture via software control.



In Recording mode, select the desired subject area by pressing the zoom buttons.

- Press [W] to reduce the zoom factor and obtain a wide-angle shot.
- Press [T] to increase the zoom factor and obtain a telephoto shot.

When pressing any of the zoom buttons the zoom bar (see page 13 – item 3) will appear on the display [12].

When the maximum optical zoom factor has been reached, zooming will pause for a moment. Press the [T] button again. The camera switches to digital zoom mode and will continue zooming in.

Optical zoom area Digital zoom area




Figure: Zoom bar on display [12]



Before you can use the digital zoom, you must enable it (see page 26, Digital Zoom).

Using the Flash

The flash [14] doesn't only enhance the brightness under bad lighting conditions. You can also use it for backlight shots or when the subject is located in shadow. In Recording mode, press the flash button (see the figure below) to toggle through the different flash modes of your Nytech DS-7210.

The flash button can be found on the four-way button:



Figure: Four-way button [9]

Flash button

With each press of the flash button the flash mode will change. This will be displayed on the LCD [12] (see page 13 – item 2). The following flash settings are available:

Icon	Description
⚡A	The flash will fire automatically whenever the shooting conditions require extra lighting.
⚡👁	A pre-flash will be sent in order for people's eyes to adapt to the flash. This will reduce the red-eye effect in your pictures. The flash will fire again to take the photo, but only when necessary.
⚡	The flash will fire always.
⚡⚡	The flash will fire for lower shutter speeds (soft flash), keeping a darker background.
🚫⚡	The flash will never fire, even in total darkness.



For burst captures (see the chapters from page 23 - Drive Mode, Burst) and for movies the flash is not available.

Record Menu

In the Quick Guide on page 16 you have learned to capture a picture by using the default settings. In this case, your Nytech DS-7210 will adjust many settings automatically to allow you to take a quick snapshot. In the Record menu, however, you may adjust many settings manually in order to meet special conditions.

All settings made here will prevail until you change them again. This will also be the case after changing the battery.

How to open the Record menu:

1. Power the Nytech DS-7210 on in Recording mode by pressing and holding the Power button [1].
2. Press the Menu button [6] to display the Record menu.
3. Press ◀ or ▶ on the four-way button to choose an item.
4. Press ▲ or ▼ on the four-way button to change the setting for the chosen item.
5. Press the Menu button [6] or the Set button [8] to save the setting and to close the menu.










The Record menu contains the following items: Resolution, Quality, Metering, White Balance, ISO, Exposure, Drive Mode, AEB, Highlight, Sharpness, Effect, Date Stamp, Digital Zoom, AF Lamp and Setup.

For more information on the different Record menu items, see the following pages.

Resolution

The resolution determines the picture quality. The following settings are available:




Icon	Picture size in pixel	Notes
	3072 x 2304	Optimum picture quality
	3072 x 2048	3:2 aspect ratio (the typical format for paper prints)
	3072 x 1728	Wide-format aspect ratio
	2560 x 1920	Enhanced quality
	2048 x 1536	Average quality
	1024 x 768	Standard PC screen
	640 x 480	Suitable for e-mails



As a general rule: The higher the resolution, the larger the picture size and the higher the storage size requirements. The lower the resolution, the more pictures can be stored. Please note that the Quality setting also influences the storage capacity requirements.




Quality

The Quality setting determines the compression ratio of the captured photo when saved onto the memory card. The higher the compression, the more pictures can be stored. The following settings are available:

Icon	Compression	Quality
	Very low	High quality
	Low	Normal quality (default)
	High	Low quality






Metering

Your Nytech DS-7210 offer three metering modes to measure the environmental lighting conditions.


Icon	Description
	The light is measured in the entire capture area but is weighted more in the centre of the picture.
	Selects an exposure according to the metering at different places in the capture area.
	Selects an exposure based on a single measurement in the picture centre.

White balance

White balance is used in photography to determine a colour temperature suitable for the current lighting conditions. The human eye has this ability, a digital camera needs a reference value to be entered first. The following settings are available:

Icon	Description
AUTO	White balance is done automatically. This setting is recommended for generic photography.
	Adjusts the white balance for bright sunlight and normal daylight conditions.
	Adjusts the white balance for cloudy days and twilight.
	Adjusts the white balance for artificial light. Corrects the orange tint of normal bulb lamps.
	Adjusts the white balance for fluorescent light. Try also the  setting.






Adjusts the white balance for fluorescent light. Try also the  setting.



Manual white balance (to enable, press the shutter button [3], see below for a detailed description).

Manual White Balance

Select **Custom WB** with the icon  from the **White Balance** menu (see above) and press the shutter halfway down. In the centre of the display [12] a frame will appear. Orientate this frame onto a white surface near the subject and then press the shutter button [3] fully down.

Now the white surface within the frame will be used as reference for the colour temperature. If the metering was successful and the colour temperature has been determined correctly, confirm the message on the display by pressing the Set button [8]. To repeat the calibration, press  on the four-way button and confirm the Back option (icon ) by pressing the Set button [8]. Then you can perform a new metering.

ISO

ISO is a unit derived from the traditional photography that determines the sensitivity of the photographic material (film). Equivalent to these values, the sensitivity of the sensor of your Nytech DS-7210 can be set. Use a smaller value for a lower sensitivity, or select a higher value to obtain a higher sensitivity to light.



A higher ISO value allows it to take pictures under bad lighting conditions. However, the picture will result more grainy. A grainy or noisy picture is the result of a technical restriction resulting in colour distortion for single pixels or pixel groups.

The following settings are available:

Option	Description
Auto	Sets the ISO sensitivity automatically
50	Equivalent to ISO 50
100	Equivalent to ISO 100
200	Equivalent to ISO 200
400	Equivalent to ISO 400

Exposure

You can set the exposure value manually. This setting depends on the lighting conditions around the subject. Select a positive value between +0.3EV and +2.0EV if you want to capture a subject located in a dark area. Select a negative value between -0.3EV and -2.0EV if the subject is very bright or shiny (e.g. a computer or a television screen) or when photographing in backlight (e.g. frontal sunlight) conditions.

Use the automatic exposure setting to have the Nytech DS-7210 determine the exposure automatically.

Drive Mode

The functions in the Drive Mode menu allow you to programme the self-timer or to enable the burst capture. The following settings are available:

Option	Description
Off	Normal single shot without any further modes.
2 sec.	Captures the photo with a 2-second delay after pressing the shutter button [3].
10 sec.	Captures the photo with a 10-second delay after pressing the shutter button [3].




- | | |
|--------|--|
| Double | Captures the photo with a 10-second delay after pressing the shutter button [3], plus a second photo after an extra 5-second delay. |
| Burst | After enabling this function you can capture a picture sequence. The camera will shoot one picture per second while you keep the shutter button [3] pressed. |

AEB (Automatic Exposure Bracketing)

This function will capture an exposure sequence. Three pictures with different exposure settings will be captured in series: normal exposure, underexposed and overexposed. This is a useful function when shooting under lighting conditions that are difficult to evaluate a priori, allowing you to obtain the correct setting without experimenting.




Highlight

This will accentuate the subject in front of its surrounding environment. Within the preset frame, the picture contents will be saved with its normal focus while the area outside the frame will result slightly blurred. The following options can be selected:

Icon	Description
	Off
	A squared picture area will be highlighted.
	Accentuation for a portrait in landscape orientation.
	Accentuation for a portrait in portrait orientation.

Sharpness

You can select whether you want your pictures to have soft or hard contours. The contour sharpness can be set in the following three levels:

Icon	Description
	The contours are sharpened, but a slight noise can be perceived in the captured image.
	The contours are sharpened. This setting is suitable for prints.
	The contours are softened.

Effect

You can already apply different effects to your images during recording. The following settings are available:

Option	Description
Off	No effects will be added.
B&W	Converts your images to black and white pictures.
Sepia	Captured images will be saved in sepia tones (giving it a vintage look).
Negative	The image will be converted to a negative (the colours are inverted).
Mosaic	The picture is converted into a mosaic.
Red	The image is tinted red.
Green	The image is tinted green.
Blue	The image is tinted blue.

Date stamp

This feature allows you to insert a stamp with the current date and time on to the picture. The following options are available:

Option	Description
Off	The capture date and time will not be displayed on the pictures.
Date	The date of the capture will be added to the images.
Date & Time	The date and time of the capture will be added to the images.

Digital Zoom

Besides the 3x optical zoom, your Nytech DS-7210 features a 4x digital zoom. You can enable it here, if desired. Digital zoom is an electronic enlargement of a portion of the image and will cause a lower picture quality than the optical zoom.



Please make sure you hold the camera completely still and stable in order to avoid shaky captures. We recommend using a tripod.

AF Lamp

The autofocus lamp helps you to take sharp pictures even under dark lighting conditions. The auxiliary light allows the camera to focus the subject properly whenever the environmental light is not sufficient.

Setup

A detailed description of this menu can be found on page 45.

Record Programmes

The record programmes give quick and easy access to preset shooting parameters for different photography conditions. Furthermore, here you can also access the video and voice recording features.










How to use the record programmes:

1. Power the camera on in Record mode (see page 11 - Switching the Camera On and Off).
2. Press the camera mode button [10] to open the Program menu (see figure).
3. Press ◀, ▶, ▲ or ▼ on the four-way button to select the desired scene mode and then press the Set button [8] to confirm the selection.




You can choose from the following preset programmes:

Icon	Description
	Program The camera will adjust automatically to the shooting conditions and performs the required settings.
	Movie To record video clips.
	Voice REC To record voice (dictaphone).
	Twilight Emphasizes the red tones for capturing sunset images.
	Backlight To capture a subject with backlight by changing the metering.
	Q Mode Facilitates beginners in capturing photos (see page 29 – Q Mode).

 Landscape	For panoramic shots.
 Portrait	The background will result slightly blurred while the focus is on the subject.
 Snow	Suitable for beach and snow captures.
 Fireworks	For fireworks scenes.
 Night Scene	The subject will be accentuated while the background will be kept as a night environment.
 Kids	Suitable for pictures of moving children.
 Food	A higher colour saturation improves the look of food.
 Building	Enhances the contours of the subject.
 Text	Enhances the black and white contrast.

Q Mode

Q mode allows you to control the camera more easily. Larger icons and fewer operating controls let newcomers and older people capture snapshots quickly.



Macro Mode

Your Nytech DS-7210 features a macro function allowing you to focus on very close subjects. The Macro mode allows you to focus on subjects from 15cm from the lens in maximum wide-angle setting (lowest zoom factor) up to 40cm in maximum telephoto setting (highest zoom factor).

The macro button can be found on the four-way button:







Figure: Four-way button [9]

1. Power the camera on in Record mode.
2. Press the Macro button (icon ) located on the four-way button [9] (see the above figure). The macro mode icon will be displayed on the LCD (see page 13 – item 6).
3. Press the shutter button [3] to take the picture.
4. To exit the macro mode, press the Macro button (icon ) again.

Recording Video Clips

Quick Guide

Your Nytech DS-7210 allows you to record video clips.

1. Press the Power button [1] to power the camera on.
2. Press the camera mode button [10] to open the Program menu.
3. Press ◀, ▶, ▲ or ▼ on the four-way button [9] to choose the option **Movie** (icon ) .
4. Press the SET button [8].
5. Use the display [12] to point the camera at the desired subject. The remaining recording time will be shown on the display (see figure).



6. Press the shutter button [3] to start recording.
7. To stop the recording, press the shutter button [3] again. To pause the recording, press ▲ on the four-way button (to resume, press again ▲ on the four-way button).



While recording a video clip you can press the zoom buttons [4]. However, while pressing the zoom buttons no sound will be recorded.


In automatic mode, white balance will be fixed to the value for the first frame.

The digital zoom is not available during video clip recording.

Video Menu

In Video menu you can adjust settings specific to video clip recording.

How to open the Video menu:

1. Press the Power button [1] to power the camera on.
2. Press the camera mode button [10] to open the Program menu.
3. Press ◀, ▶, ▲ or ▼ on the four-way button [9] to choose the option **Movie** (icon ) .
4. Press the SET button [8].
5. Press the Menu button [6].
6. Press ◀ or ▶ on the four-way button to choose an item.
7. Press ▲ or ▼ on the four-way button to change the setting for the chosen item.
8. Press the Menu button [6] or the Set button [8] to save the setting and to close the menu.



The Video menu contains the following items: Movie Size, Metering, White Balance and Setup.

For more information about the different Video menu items, see the following pages.

Movie Size

The movie size determines the size of the recording in pixels. As a general rule: The higher the resolution, the more storage space is required. The frame rate of 30 frames per second will remain constant. The following settings are available:

Setting	Resolution in pixels	Description
640	640 x 480	Highest quality
320	320 x 240	Average quality
160	160 x 120	Low quality

Metering

For the settings available for Metering, please see the Record menu (page 21 – Metering).

White balance

For the settings available for White Balance, please see the Record menu (page 21 – White Balance).

Setting

A detailed description of this menu can be found on page 45.

Playing Back Images and Video Clips

Quick Guide

You can use the display [12] of your Nytech DS-7210 to view captured pictures and videos.

1. Power the Nytech DS-7210 on in Playback mode by pressing and holding the Play button [5]. The last recorded picture will appear on the display [12] (if the memory is empty, the message **No image** will appear).
2. Press ◀ or ▶ on the four-way button [9] to scroll along the recorded photos, video clips or voice recordings.



Keep the buttons ◀ or ▶ pressed for fast scrolling.

3. If the file is a video clip or a voice recording, or if the picture contains a voice note, the icon [▲ : Play] will appear. Press ▲ on the four-way button [9] to play the recording.

During playback, you can use the four-way button [9] for the following:

- ▲ Pauses playback.
- ▼ Stops playback
- ▶ Fast forward playback (only for video clips)
- ◀ Fast backward playback (only for video clips)



During video clip playback you can freeze the image and capture it as a photo. To do so, press ▲ on the four-way button [9] to pause the playback at the desired frame and press the shutter button [3]. The picture will be captured and displayed in playback mode.

Playback Menu

The Playback menu offers different ways to edit your recordings.

How to open the Playback menu:


1. Power the Nytech DS-7210 on in Playback mode by pressing and holding the Play button [5].
2. Press the Menu button [6] to display the Playback menu.
3. Press ◀, ▶, ▲ or ▼ on the four-way button [9] to choose an item.
4. Press the SET button [8] to change or enable the selected setting.
5. Press the Menu button [6] again to return to Playback mode.





The Playback menu contains the following items: Lock, Delete, Slide Show, DPOF, Copy to card, Effect, Rotate, Resize, Voice Memo, Start-up Image, and Setup.

For more information about the different Playback menu items, see the following pages.

Lock

This feature allows you to protect your recordings (pictures, video clips or voice recordings) against accidental erasure or unwanted editing. To enable it, select the  icon from the Playback menu and press the SET button [8]. The subsequent menu contains the following options:


Option	Description
Single	Protects the currently selected recording.
Lock all	Protects all saved recordings.
Unlock all	Unlocks all the previously protected recordings.
	Back to Playback menu.

In any case, a safety prompt will appear that you have to confirm by pressing the SET button [8]. Otherwise the action will not be executed. If you made a mistake, you can cancel the dialogue by selecting the  icon.





To unlock a single recording, repeat the steps for unlocking a single picture.


Delete


You can delete any undesired recordings or those that don't match your expectations in order to make more space available on the memory card. To enable this, select the  icon from the Playback menu and press the SET button [8].

The subsequent menu contains the following options:



Option	Description
Single	Deletes the currently selected recording.
All	Deletes all saved recordings.
	Back to Playback menu.


In both cases, a safety prompt will appear that you have to confirm by pressing the SET button [8] otherwise the deletion will not be executed. If you made a mistake, you can cancel the dialogue by selecting the  icon.






Locked pictures cannot be deleted.



If you want to delete the entire memory card, please also see page 48 – Format.


Slide Show

The slide show will play back all saved recordings in sequence. For video clips, the first frame will be shown, voice recordings are skipped. To launch a slide show, select the  icon from the Playback menu and press the SET button [8].


From the menu that appears, if necessary, select more options by pressing  or  on the four-way button [9] (see below) and start the slide show by pressing the SET button [8].




Option	Description
 Interval	Sets the display time for each picture (1s to 15s).
 Music	Select one of three different music styles for the background music or select None if you

-  Effect

don't want to listen to any music.

Select a specific transition effect or select **Mix** for random effects.
-  Repeat

Specify whether you want the slide show to restart from the beginning once completed.
- 


Back to Playback menu.











During playback, press the SET button [8] to pause the slide show. Press SET again to resume the playback.

DPOF

DPOF (Digital Print Order Format) allows you to embed printing information on your memory card. By using DPOF, you can select an image to be printed and then specify how many prints or which image you would like. This is extremely convenient for sending the images to a photo developing service or for printing on a direct print function compatible printer.


To enable it, select the  icon from the Playback menu and press the SET button [8].






1. Press  or  on the four-way button [9] to choose if you want include one picture (**Single**) or all pictures (**All**). You can also select **Reset** to delete any previous settings.
2. In the menu that appears (see figure), press  or  to set the number of copies to print (1 to 30).
3. Next press  and then  or  to specify whether to print a date stamp on the picture or not.
4. Press the SET button [8] to apply the settings.
5. Press the Menu button [6] to return to Playback mode.



Copy to card

You can copy pictures stored in the internal memory of your Nytech DS-7210 onto the SD card.

To enable it, select the  icon from the Playback menu and press the SET button [8].


1. Press  or  on the four-way button [9] to choose if you want to copy one picture (**Single**) or all pictures (**All**). Press  to go back to the Playback menu without making any changes.
2. Press the SET button [8] to confirm your selection.
3. Press the SET button [8] to confirm the message.
4. If you selected **Single** in step 1, you can press  or  to select more pictures and then repeat step 3.
5. Press the Menu button [6] to return to Playback mode.

Effect

For the settings available for Effect, please see the Record menu (page 25 – Effect).

Rotate

You can rotate recorded images in 90-degree steps. This is a very useful function if you have captured pictures in portrait format.

To enable it, select the  icon from the Playback menu and press the SET button [8].

The following options are available:


Option	Description
Rotate	Each press of the SET button [8] will rotate the image 90° clockwise.
OK	Saves the rotated image.



Back to Playback menu without saving any changes.

Resize

You can reduce the resolution of a saved picture to free-up some memory on the memory card or to convert the image to send it via e-mail.

To enable it, select the  icon from the Playback menu and press the SET button [8].


1. In the following menu, press ▲ or ▼ on the four-way button to select the desired resolution (see also page 20 – Resolution).
2. Press the SET button [8] to confirm. The picture will be saved with the new resolution.




It is only possible to resize pictures with a high resolution into pictures with a lower resolution. It is not possible the other way round.

Voice Memo

After recording a picture you can attach a voice memo.

To enable it, select the  icon from the Playback menu and press the SET button [8].

1. If there is already a voice memo attached to the picture, the  icon is displayed (see page 12 – item 3). Recording a new voice recording will delete any existing one.
2. Press the SET button [8] to start a maximum 30-second recording.
3. Press SET again to stop recording.




It is not possible to attach a voice memo to video clips or locked images.

Voice memos can be deleted separately. When deleting a picture with an attached voice memo, the voice memo will also be deleted.

Start-up Image

You can configure any picture as a start-up image. This will appear when powering on your Nytech DS-7210. Select the start-up image from this menu. In the Setup menu (see page 48 – Setup - Start-up Image) you can enable the image.

To enable it, select the  icon from the Playback menu and press the SET button [8].

1. If required, press ◀ or ▶ on the four-way button to select the picture you want to use as a start-up image.
2. Press the SET button [8] to confirm. The new start-up image will be copied. After a few seconds, the message “Completed” will appear.
3. Or press ▼ and then the SET button [8] to cancel the process.
4. Press the Menu button [6] to return to Playback mode.

Setting

A detailed description of this menu can be found on page 45.

Using the Thumbnail View


The thumbnail view allows you to show nine pictures at the same time on the display [12]. This feature helps you find a specific picture faster and to obtain a better overview of your recordings.

1. Power the Nytech DS-7210 on in Playback mode by pressing and holding the Play button [5].
2. Press [W] on the Zoom button [4] to toggle to thumbnail view.
3. Press ◀, ▶, ▲ or ▼ on the four-way button [9] to select the desired picture and then press the [T] or the SET button [8] to view the picture in full size. After this the camera will be in playback mode.

Enlarging Pictures

Select a specific portion of an image and save it as a new image.


1. Power the Nytech DS-7210 on in Playback mode by pressing and holding the Play button [5].
2. Press [T] on the Zoom button [4] to toggle to trimming mode.
3. Press [T] on the Zoom button to zoom in the picture, press [W] to zoom out.
4. Press ◀, ▶, ▲ or ▼ on the four-way button to move the enlarged section.
5. Press the SET button [8] to trim the currently displayed image section.
6. Press the SET button [8] again to save the trimmed image.



Audio Recording and Playback

Audio Recording

You can use your Nytech DS-7210 to record voice (dictaphone). To do so, press the Power button [1] to power the camera on.

1. Press the camera mode button [10] to open the Program menu (see also page 26 - Record Programmes).
2. Press ◀, ▶, ▲ or ▼ on the four-way button [9] to choose the option **Voice REC** (icon .
3. Press SET [8] to confirm your selection.
4. Press the shutter button [3] to start recording.
5. Press the shutter button [3] to stop recording.



The remaining recording time will appear on the display [12] during recording.

Voice recording takes place via the camera's microphone [16]. Make sure that you don't touch the microphone during recording to avoid any noise.

Audio Playback

You can use the Playback mode to listen to your audio recordings.

1. Power the Nytech DS-7210 on in Playback mode by pressing and holding the Play button [5].
2. Press ◀ or ▶ on the four-way button [9] to scroll along the recorded photos, video clips or voice recordings.



Keep the buttons ◀ or ▶ pressed for fast scrolling.

3. If the file is a voice recording (or if the picture contains a voice note), the icon [▲ : **Play**] will appear. Press ▲ on the four-way button [9] to play the recording.

During playback, you can use the four-way button [9] for the following:


- ▲ Pauses playback.
- ▼ Stops playback

Advanced Settings


Setup Menu

The Setup menu contains basic control and functional options of your Nytech DS-7210. You can access this menu from any of the main menus (see page 27 – Record Menu - Setup, page 32 Video Menu – Setup and page 40 Playback Menu - Setup).

On the following pages, we will use the access via the Record menu to go to the Setup menu settings.

1. Power the camera on by pressing and holding the Power button [1].
2. Press the Menu button [6] to toggle to the Record menu.
3. Press ◀ or ▶ on the four-way button [9] to select **Setup** (icon ) and then press the Set button [8] to open the Setup menu.

The Setup menu consists of three levels. Our example shows the first level. Press ▲ or ▼ on the four-way button to choose any option. When reaching the last option, the next menu level will appear.



4. Press the SET button [8] to select an option.
5. Press ◀, ▶, ▲ or ▼ on the four-way button [9] to choose or change the different menu options. Press the SET button [8] to apply the changes.



The Setup menu contains the following items: Sounds, Auto Review, Power Save, Date & Time, Language, File No., TV Out, USB, Start-up Image, Format and Reset All.

For more information about the different Setup menu items, see the following pages.

Sounds

This menu allows you to perform the following sound settings:

Option	Description
Shutter	Choose whether the Nytech DS-7210 should emit a sound when pressing the shutter button [3].
Start-up	Select one of three available start-up sounds.
Beep	Choose whether you want to hear a beep when pressing any button.
Volume	Here you can choose from four different volume levels for the acoustic signals.

Auto Review

Here you can choose if you want your Nytech DS-7210 to display a picture immediately after recording. This function will display the recorded picture upon recording for a preset time.

Option	Description
Off	No Auto Review
3 sec.	Display time: 3 seconds
5 sec.	Display time: 5 seconds

Energy-Saving Function

When the Nytech DS-7210 is left powered on but not used, it will power off automatically. This function has been designed to save battery power. Also read page 11 – Power-Saving Function.

You can choose between three power-off timers: 1 minute, 3 minutes or 5 minutes.

Date & Time

You have already read about this feature in the Getting Started chapter. Please read page 15 – Setting Date and Time.

Language

You have already read about this feature in the Getting Started chapter. Please read page 15 – Setting the Menu Language.

File Number

Your Nytech DS-7210 will automatically assign a unique name to your recordings. This file name is a combination of the prefix “DSCI” followed by a sequential four-digit number (starting at 0001).

You can select the **Reset** function from this menu to reset the sequential number back to 0001. To avoid double names, your Nytech DS-7210 will automatically create a new folder on the memory card.

TV Out

This menu allows you to select the TV standard of your television set. The standards **PAL** and **NTSC** are available. In Europe, PAL is generally the standard whereas NTSC is the standard on the American continent and in Asia.

USB

Here you can set whether you have connected a computer or a direct printer to the USB port.

Start-up Image

Select a start-up image for your Nytech DS-7210. The following options are available:

Option	Description
Off	No start-up image
System	Built-in start-up image of your camera
My image	Custom start-up image (please read on page 40 how you can set a start-up image to be able to select it here)

Format

This function lets you delete all contents from your memory card and renew the file saving structure on your card (formatting). Select **Yes** to remove all the contents from the memory card or select **No** to go back to the Setup menu without applying any changes.



Warning! Formatting will delete all pictures, video clips and voice recordings from your memory card. Make sure that all recordings that you want to keep have been backed-up on a different media.

Reset All

All Nytech DS-7210 menu settings will be reset to the factory-default settings. This function applies to the camera menu settings only, not to the information stored on the memory card or the internal memory.


Select **Yes** to reset all settings to the factory defaults or select **No** to go back to the Setup menu without applying any changes.

Connectors

Viewing Pictures on a Television Screen

Any pictures that you can view on the Nytech DS-7210 display [12] can also be played back on a regular TV set. For this, your television set must have an appropriate Video In connector.

Use the supplied AV cable to connect the product to a television set.



1. Power your Nytech DS-7210 off.
2. Insert the AV cable connection jack into the connection port of your camera (see above figure).
3. Insert the AV connection jacks into the corresponding inputs of your TV set (yellow connector to VIDEO IN, white connector to AUDIO IN). Please also consult your TV set's User Manual for more information.
4. Select the AV channel corresponding to the above input connectors on your TV set. This is a device-specific setting. If necessary, read the User Manual of your TV set for more information on how to do this.
5. Power the camera on in Playback mode by pressing and holding the Play button [5].

The display [12] on the camera will remain off while the AV cable is connected to the AV port. Instead, the pictures will be played back on your television set. Control the camera as usual, e.g. start a slide show (see page 36 – Slide Show) to play all images automatically.



If the picture is only displayed in black and white on the TV make sure that the TV system setting is correct for your TV (see page 47 – TV Out).



Power the Nytech DS-7210 off prior to connecting or disconnecting the AV cable to/from the camera.

Copying Pictures to a Computer


There are two possible ways to copy pictures from the Nytech DS-7210 to a computer:

1. by connecting the camera to a computer via the USB cable
2. by inserting the SD memory card into a card reader

Using the USB Cable


Windows® 2000/XP operating system will detect the camera automatically as a mass storage device. If you're using Windows® 98SE it is necessary to install the required driver first. To do so, insert the supplied CD-ROM into the CD drive of your computer and launch the driver installation. Follow the on-screen instructions and restart your computer when prompted to do so.

Click [here](#) to launch the driver installation for Windows 98SE (menu option “Drivers”).




Note: If this menu isn't displayed automatically after inserting the CD-ROM, you can run the file “autorun.exe” from the CD-ROM manually.

After you have successfully installed the driver for Windows 98SE or if you're using Windows 2000/XP, you can use the USB cable to connect the Nytech DS-7210 to your computer.



1. Power your Nytech DS-7210 off.
2. Insert the USB cable connection jack into the connection port of your camera (see above figure).
3. Plug the USB connector into a free USB port on your computer.
4. Press the Power button [1] to power the camera on. The computer will detect the camera as a "Removable disk" and will create a new drive with the next available driver letter.
5. Open My Computer on your PC and double-click on the new "Removable disk" drive.

- All recorded files can be found in the folder "DCIM" on this disk drive.



- Now you can copy the recorded files from the camera into a folder of your choice of the computer's hard disk.



Be careful when renaming any folders and files. Do NOT try to change the folder or file names stored on the camera from the computer. Otherwise you may not be able to play back any files contained here with your Nytech DS-7210.


After you have copied your files or folders to the computer, you can rename or edit them on the computer.

Using a Card Reader

If your computer features a card reader supporting SD memory cards, you can read the memory card's contents directly. To do so, power the Nytech DS-7210 off and remove the memory card (see page 10 - Inserting the SD Card).

- Insert the memory card into the card reader of your computer (normally labelled SD/MMC).
- The PC will add the memory card contents under the drive letter in My Computer representing the card reader.
- Open My Computer on your PC and double-click on the disk drive representing the card reader.
- All recorded files can be found in the folder "DCIM" on this disk drive.

Memory card in PC card reader



5. Now you can copy the recorded files from the memory card into a folder of your choice on the computer's hard disk.



Be careful when renaming any folders and files. Do NOT try to change the folder or file names stored on the memory card from the computer. Otherwise you may not be able to play back any files contained here with your Nytech DS-7210.

After you have copied your files or folders to the computer, you can rename or edit them on the computer.

Installing the Software

System Requirements

- Personal Computer with Pentium MMX 233 MHz processor or higher
- Windows XP/2000/98SE
- Minimum 32 MB RAM
- Free USB port
- CD-ROM drive


Supplied Software

The supplied CD-ROM contains driver and software for your Nytech DS-7210.

Insert the CD-ROM into your CD-ROM drive. The menu should appear automatically.



Note: If this menu isn't displayed automatically after inserting the CD-ROM, you can run the file "autorun.exe" from the CD-ROM manually.



The following software will be listed:

- Ulead Photo Explorer 8 SE Basic
Installs software for organising and managing your media files.
- VideoStudio 7 SE VCD
Installs video-editing software.
- Utilities
Installs several helpful utilities for playing back different media formats as well as the program Adobe Acrobat Reader for viewing documents in PDF format.
- User Manual
Opens this User Manual.
- Drivers
Installs the camera driver for Windows 98SE (see page 50 - Using the USB Cable).
- Browse CD
Opens Windows Explorer for browsing the CD contents.
- Exit
Closes this menu.

Click on the software you want to install and follow the on-screen instructions.

Appendix

Power Indicator Status

The power indicator [2] of your Nytech DS-7210 informs you of the camera status. Depending on its colour and/or blinking frequency it has the following meanings:

Steady green, display on:

The camera is ready in Record mode.

Steady green, display off:

The camera has been connected to the TV set via the AV cable or it has been connected to a computer via the USB cable.

Blinking green, display off:

The camera is in power-saving mode (press any button to exit the power-saving mode).

Blinking green, display on:

The autofocus was unable to focus the image (change the camera position or the zoom factor and retry the autofocus again).

Steady red:

The autofocus was able to focus the subject. The settings for aperture and shutter speed will prevail as long as the shutter button is kept pressed down.

Fast blinking alternating red and green:

After capturing an image, the camera isn't ready yet for the next picture (for instance when using the flash). Wait until the power indicator lights steady green.

Tips for Taking Better Pictures

Camera technology alone is not only responsible for producing good shots. Here you can find some tips for taking better pictures.

Subject

The subject is the main item of the picture, therefore you should pay special attention to the subject. However, the subject doesn't always need to be spectacular – trivial scenes may also make a great subject and thus a great picture.

Background

The background shouldn't distract from the subject. Make sure that no interfering objects are located in the background.

Camera Angle

Experiment with the angle. Change your position relative to the subject and try both a wide-angle or a telephoto setting.

Golden Section

The Nytech DS-7210 allows you to display a grid while in Record mode (see page 14 - Changing the Displayed Information). Place important subject parts onto the grid lines or on their intersections (e.g. the horizon).

Lighting

Lighting conditions reflect the atmosphere of a scene. Therefore try to avoid using the flash when you are attempting to take pictures under candlelight. When disabling the flash, the Nytech DS-7210 will automatically use a longer exposure time. In this case, place the camera on a stable surface or use a tripod.

Troubleshooting

Problem	Reason	Solution
Unable to power the camera on.	The rechargeable battery isn't inserted properly.	Remove the rechargeable battery and insert it respecting the correct polarity.
	The rechargeable battery is exhausted.	Replace the battery or recharge it.
	The battery compartment cover isn't closed.	Close the battery compartment cover.
The camera does not record any pictures.	The flash is still charging (power indicator blinking fast).	Wait until the flash has been charged.
	The memory is full.	Insert an empty memory card or delete some recordings.
	The memory card isn't properly formatted.	Format the memory card or try with a different memory card.
	The maximum number of files (9999) has been exceeded).	Reset the file number.
The flash does not fire.	The flash is disabled.	Enable the flash or select a programme with flash.

Troubleshooting (continued)

Problem	Reason	Solution
The picture is distorted or blurred.	The camera has moved during capture.	Hold the camera still.
	The subject was located outside the focus range of the camera.	Change your relative position to the subject. Use the Macro mode when capturing very close subjects.
Recorded images haven't been saved.	The camera has been powered off before any picture could be saved.	Don't power the camera off before the power indicator lights steady green.
Unable to transfer any pictures to the computer after connecting the USB cable.	The USB driver is not installed.	Install the USB driver before connecting the camera to a computer. You have to do this only once.

Technical Specifications

Capture sensor	7 megapixel CCD
Lens	Optical zoom: 3x Focus range: $f = 6.2\text{mm} - 18.6\text{mm}$ Aperture: $F = 2.8 - 5.2$
Range	Normal mode: 60cm – infinity Macro mode: Wide-angle 15cm – 1m, Telephoto 40cm – 1m
Colour LCD Display	2.5-inch TFT LCD display
Shutter speed	1/2000s – 8s
File format	Photo: JPEG, DCF-compatible; supports DPOF Video: MPEG 4 Audio: WAV
Resolution	Photo: 3072x2304, 3072x2048, 3072x1728, 2560x1920, 2048x1536, 1600x1200, 640x480 Video: 640x480, 320x240, 160x120
Scene mode	Auto, Movie, Voice recording, Twilight, Backlight, Q Mode, Landscape, Portrait, Snow, Fireworks, Night Scene, Kids, Food, Building, Text
Sensitivity	Auto, ISO50, 100, 200, 400
White balance	Auto, Daylight, Cloudy, Tungsten, Fluorescent H, Fluorescent L, Custom
Exposure compensation	-2.0EV to +2.0EV
Metering	Multi-field, Multi and Spot metering
Self timer	2s, 10s, Double
Flash	Auto, Red-eye reduction, Always on, Slow synchronisation, Always off

Technical Specifications (continued)

Photographic effects	Black and white, Negative, Sepia, Mosaic, Red, Green, Blue
Memory	Internal: 16 MB flash memory External: SD/MMC memory card
TV Out	PAL, NTSC
Power supply	Rechargeable Lithium-Ion battery: 3,7V, 820mAh (BYD DM6331) Power adapter: Ktec KSAF B 060 0050 W1 UK
Temperature	Operating temperature: 0° - 35° Storage temperature: -20° - 60°
Microphone	Built-in mono condenser microphone
Speaker	Integrated
Dimensions	90 x 56 x 23mm (W x H x D)
Weight	Camera case without battery: approx. 110g

Details of Guarantee

**36 month warranty from
date of purchase**



Important warranty information



Dear Customer,

Thank you for purchasing a Nytech product.

Please carefully read through the enclosed documentation or online help before putting your Nytech product into service. If you have a problem, which can't be solved in this way, please contact our hotline.

If the problem cannot be solved over the phone, you will be given a reference number (RMA), which you should enclose together with a copy of the proof of purchase. After you have packaged the unit safe for transport and in plain packaging, please send it for warranty processing, with the RMA noted on the outside of the package, to the address given to you by our hotline employee. After receiving the unit we will correct the manufacturing and material defect free of charge.

Up-to-date information and answers to the most frequently asked questions are available on the internet from:

www.nytech.de

This guarantee is valid in the UK.

Your statutory guarantees from the seller are in addition to this warranty and are not limited by it.



**Hotline number:
0207-3650744**

(Please have your
serial number to hand!)

Manufacturer: Targa GmbH, Postfach 2244,

D-59482 Soest

www.nytech.de

36 month warranty from date of purchase



Important warranty information



Dear Customer,

Thank you for purchasing a Nytech product.

Please carefully read through the enclosed documentation or online help before putting your Nytech product into service. If you have a problem, which can't be solved in this way, please contact our hotline.

If the problem cannot be solved over the phone, you will be given a reference number (RMA), which you should enclose together with a copy of the proof of purchase. After you have packaged the unit safe for transport and in plain packaging, please send it for warranty processing, with the RMA noted on the outside of the package, to the address given to you by our hotline employee. After receiving the unit we will correct the manufacturing and material defect free of charge.

Up-to-date information and answers to the most frequently asked questions are available on the internet from:

www.nytech.de

This guarantee is valid in the Ireland.

Your statutory guarantees from the seller are in addition to this warranty and are not limited by it.



**Hotline number:
01-2421583**

(Please have your
serial number to hand!)

Manufacturer: Targa GmbH, Postfach 2244,

D-59482 Soest

www.nytech.de